

SEAT SWIVELS RANGE



VERY HIGH QUALITY ENGINEERED SEAT SWIVEL BASES CE APPROVED

As a safety critical item seat swivels are CE approved for peace of mind. You only find out how good your seat swivel is when you survive to tell the tale. Build quality of seat swivels is imperative, as it has to meet or exceed the strength of the vehicle manufactures design criterion for seat & seat belt mountings. Short cutting in this area is unsafe and unwise. Within the FASP, CTA and RIB ranges are swivels engineered to the highest automotive standards to meet or exceed the requirements of the Original Vehicle Manufacturer. The swivels are fabricated from heavy gauge steel & swivel around a large central pivot. The swivel plates sandwich a special self lubricating nylon wear plate thereby making the swivel virtually maintenance free.

Fixing bolts are not supplied with FASP swivels; use the equivalent or stronger bolts to the same design as the bolts installed by vehicle manufacturer. The strength rating is usually stamped into the head of the bolt (8.8, 10.2 or 12) as well as the size (M8, M10, etc.) please ensure you use suitable bolts.

CE certification standards (a) TESTED and APPROVED according to CEE 96/38 & or 2005/41/CE. (b) HOMOLOGATED according to CEE 96/37 - 96/38 Please note Fiat Ducato, Peugeot Boxer and Citroen Relay are one and the same chassis with no differences in seat swivel installation.



Universal seat Swivel+ Ducato, Talbot Express, Citroen. Pre 1994 only 430 x 350mm. FASP. SWVL1R For RH seat SWVL1L For LH seat



SWVL3R Boxer, Ducato, Relay, RH drivers 1994 to 2006 model year. SWVL3L Boxer, Ducato, Relay, LH passenger 1994 to 2006 model year. Re-use seat belt mounting on seat 430 x 350mm (3R pictured) FASP



SWV3CT For LH or RH seat 1994-2006 Ducato, Boxer & Relay



X250 swivel for New Ducato. Boxer and Relay. 2006 on. FASP SWVL7R For RH seat SWVL7L For LH seat



X250 swivel for New Ducato, Boxer and Relay. 2006 on. CTA SWV7CT44 For LH or RH seat H=44mm Need to trim existing seat box front cover. Or use code to get new box front below.



X250 swivel for New Ducato. Boxer and Relay. 2006 on. SWV7CTBOX For LH or RH seat H=44mm includes new under seat cover. CTA



X250 swivel for New Ducato.

VW T4 swivel pre 96 Threaded pegs on seat box. Boxer and Relay. 2006 on. CTA 426 x 404mm SWV7CT54 For LH or RH seat SWVL4R VW T4 pre 96 RH H=54mm Taller swivel to miss ex-SWVL4L VW T4 pre 96 LH isting seat box front cover. (4R pictured) FASP



VW T4 swivel 1997 on. Bolt holes on seat box. 426 x 404mm SWVL6R For RH seat SWVL6L For LH seat **FASP**



SWVL16R For RH seat SWVL16L For LH seat New VW T5 seat swivel 2004 on. 454mm x 464mm Drivers requires a handbrake lowering

bracket to install. FASP



X250 Seat box cover fitted

SWVL16HBA

VW T5 Handbrake adaptor

for installing RH UK drivers

seat swivel.



SWVL10R For RH seat SWVL10L For LH seat New Renault Master & Vauxhall-Opel Movano Interstar 2004 on. FASP 400 x 335mm (10R pictured)



SWV10CT For LH or RH seat. Master, Movano, Interstar 2004 on.



SWVL17R For RH seat SWVL17L For LH seat New Renault Traffic Vauxhall Vivaro Primastar seat swivel 2002 on Picture for illustration(not of product) FASP



SWVL5R Merc Sprinter 96-> 06 VW LT 1997 on. RH drivers. SWVL5L Merc Sprinter 96-> 06 VW LT 1997 on. LH passenger. 440 x 425mm (5L pictured)



SWV5CT For LH or RH seat Merc Sprinter 96-06 & LT 1997 on, CTA



Mercedes Sprinter VW Crafter 2006 on SWV18RIBR RH Drivers SWV18RIBL LH Passenger

SWV18RIBHB Soft Hand-

brake cover to install swivel



Citroen Dispatch, Peugeot Expert, Fiat Scudo 2007 ON

SWV20RIBR RH Drivers

SWV20RIBL LH Passenger

Picture for illustration(not of

product)

Mercedes Vito / Viano 2004 on. SWV12RIBR RH Drivers SWV12RIBL LH Passenger



SWV13CT Ford Transit 2000 On. Left or Right hand seat.



SWV15CT For LH or RH seat Iveco Daily 1999/2000 onwards.

SEAT SWIVEL INSTALLATION GUIDANCE

For most installations the seat swivel will be installed onto the seat box with the seat and seat runners on top of the swivel. Firstly where fitted remove the seat belt from the anchor point on rear end of seat slide. Then remove the four or six bolts holding seat to sliders and retain. Now remove the four or six bolts holding sliders to seat box and retain. Purchase from the vehicle manufacturers main dealer four or six bolts to the same strength specification as the ones removed from the seats. Bolt the swivel onto the seat box with the original bolts used. Now bolt the seat slides onto the top plate of the swivel using the new bolts purchased. Next bolt the seat back onto the seat slides using the original bolts. Finally re fit the seat belt to its anchor point if removed. For some applications it will be the case that the swivel is installed between the sliders and the seat. This will be evident by the bolt hole positions.

STANDARD SEAT SWIVELS

Are needle bearing standard swivels (BAS codes) to suit most seat boxes provide a lower cost alternative, while maintaining high quality engineering standards. Pressure plate technology maintains strength. (Not certified)



BAS1C Standard swivel + pre 94 Ducato. 425 x 355mm



BAS1C02 Standard swivel 02-06 Ducato. 425 x 355mm



BAS5C Standard swivel Merc Sprinter 96->06 / VW LT. 470 x 425mm



BAS6C Standard swivel Master, Movano, Interstar



BASTR00 Standard swivel Ford Transit 2001- 2006 and 2006 on. 480 x 470mm

WE NOW OFFER INSTALLATION AND SAFETY INSPECTION SERVICE BY SupremeTech.co.uk



